



PMC - 790

Industrial Liquid Rubber Compound

PRODUCT OVERVIEW

PMC-790 is a new Shore 90A industrial urethane rubber compound designed to meet the most stringent requirements of industrial production applications. It is a very hard rubber that offers superior tear and tensile strength as well as impact and abrasion resistance. It is a worthy addition to our extensive PMC line.

PMC-790 is suitable for a variety of industrial applications including making concrete stamping pads, mold liners and molds for casting concrete. PMC-790 is also good for making ball mill liners, industrial rollers and belts, rubber mechanical parts and for bonding itself or other substrates to metal.

TECHNICAL OVERVIEW

Key Values: ~*Mixing Ratio:* 2A : 1B by weight or volume. ~*Shore A Hardness:* 90
 ~ *Pot Life:* 20 minutes ~ *Cure Time/Demold:* 48 hours at 77°F / 25°C. ~ *Color:* Clear Amber

| Properties | Viscosity | G/CC | Cu. In./Lb. | Tensile Strength | Mix Ratio |
|---------------------------------|-----------|------|-------------|---------------------------|------------|
| Part A | - | - | - | - | 200 |
| Part B | - | - | - | - | 100 |
| Mixed | 3,000 cps | 1.07 | 25.9 | >2,000 psi | - |
| Elongation At Break . . . | 550%* | | | Die C Tear Strength . . . | 300 pli |
| Ultimate Tensile Strength . . . | >2000 psi | | | Shrinkage | negligible |

*readings taken after material was allowed to cure for 48 hours at 77° F / 25° C.

Start By Preparing Your Model -

Preparation . . . Store and use at room temperature. Material has a limited shelf life and should be used as soon as possible. Wear safety glasses, long sleeves and rubber gloves to minimize contamination risk. Good ventilation (room size) is necessary.

Some Materials Must Be Sealed . . . To prevent adhesion between the rubber and model surface, models made of porous materials (gypsum plasters, concrete, wood, stone, etc.) must be sealed prior to applying a release agent. *Sonite Wax™* (available from Smooth-On) is suitable for sealing porous surfaces. Apply two thin layers of wax and let dry. A high quality Shellac is suitable for sealing modeling clays that contain sulfur or moisture (water based). Thermoplastics (polystyrene) must also be sealed with shellac or PVA. **In all cases**, the sealing agent should be applied and allowed to completely dry prior to applying a release agent.

Non-Porous Surfaces – metal, glass, hard plastics, sulfur free clays, etc. require only a release agent.

Applying A Release Agent . . . A release agent is necessary to facilitate demolding when casting into or over most surfaces. Use a release agent made specifically for mold making (Universal Mold Release available from Smooth-On). A liberal coat of release agent should be applied onto all surfaces that will contact the rubber. ~**IMPORTANT:** To ensure thorough coverage, lightly brush the release agent with a soft brush over all surfaces of the model. Follow with a light mist coating and let the release agent dry for 30 minutes.

Because no two applications are quite the same, a small test application to determine suitability for your project is recommended if performance of this material is in question.

Measuring & Mixing . . .

Liquid urethanes are **moisture sensitive** and will absorb atmospheric moisture. Mixing tools and containers should be clean and made of metal, glass or plastic. Materials should be stored and used in a warm environment (72° F / 22° C).

IMPORTANT: Shelf life of product is drastically reduced after opening. Immediately replacing the lids on both containers after dispensing product will prolong the shelf life of the unused product. **XTEND-IT Dry Gas Blanket** (available from Smooth-On) will significantly prolong the shelf life of unused liquid urethane products. This product has a limited shelf life and should be used as soon as possible. Wear safety glasses, long sleeves and rubber gloves to minimize contamination risk.

Important: Pre-Mix the Part B before using. After dispensing proper amounts of Parts A and B into mixing container, mix thoroughly for at least 3 minutes making sure that you scrape the sides and bottom of the mixing container several times. **If Mixing Large Quantities** (24 lbs./10.88 kgs. or more) at one time, use a mechanical mixer (i.e. Squirrel Mixer or equal) for 3 minutes followed by careful hand mixing for one minute as directed above. Then, pour entire quantity into a new, clean mixing container and do it all over again.

Although this product is formulated to minimize air bubbles in your the cured rubber, vacuum degassing will further reduce entrapped air. A pressure casting technique using a pressure chamber can yield totally bubble free castings. Contact Smooth-On or your distributor for information about vacuum degassing or pressure casting.

Pouring

Curing

Performance

For best results, pour your mixture in a single spot at the lowest point of the containment field. Let the rubber seek its level up and over the model. **A uniform flow will help minimize entrapped air.** The liquid rubber should level off at least 1/2" (1.3 cm) over the highest point of the model surface.

Curing . . . Allow rubber to cure for at least 48 hours at room temperature (77 F/25 C) before demolding. Do not cure rubber in temperatures less than 65° F / 18° C.

Post Curing – After rubber has cured at room temperature, heating the rubber to 150° F (65° C) for 8 hours will increase physical properties and performance.

Using The Mold . . . If using as a mold material, a release agent should be applied to the mold before each casting. The type of release agent to use depends on the material being cast. The proper release agent for **wax, liquid rubber or thermosetting materials** (i.e. Smooth-On liquid plastics) is a spray release made specifically for mold making (Universal Mold Release). Prior to casting **gypsum plaster materials**, sponge the mold with a soap solution for better plaster flow and easy release. **In & Out Water Based Release Concentrate** (available from Smooth-On) is recommended for releasing abrasive materials like **concrete**.

Performance & Storage - Fully cured rubber is tough, durable and will perform if properly used and stored. The physical life of the rubber depends on how you use it. Contact Smooth-On directly with questions about this material relative to your application.

SAFETY FIRST

SAFETY FIRST

SAFETY FIRST

The Material Safety Data Sheet (MSDS) for this or any Smooth-On product should be read prior to use and is available upon request from Smooth-On. All Smooth-On products are safe to use if directions are read and followed carefully.

Be careful. Part A is a TDI prepolymer. Vapors, which can be significant if material is heated or sprayed, cause lung damage and sensitization. Use only with adequate ventilation. Contact with skin and eyes may cause severe irritation. Flush eyes with water for 15 minutes and seek immediate medical attention. Remove from skin with waterless hand cleaner followed by soap and water. Prepolymers contain trace amounts of TDI which, if ingested, must be considered a potential carcinogen. Refer to MSDS .

Part B is irritating to the eyes and skin. If contaminated, flush eyes with water for 15 minutes and seek immediate medical attention. Remove from skin with soap and water. When mixing with Part A follow precautions for handling isocyanates. **Important:** The information contained in this bulletin is considered accurate. However, no warranty is expressed or implied regarding the accuracy of the data, the results to be obtained from the use thereof, or that any such use will not infringe upon a patent. User shall determine the suitability of the product for the intended application and assume all risk and liability whatsoever in connection therewith.

For Technical Help: Tel. (800) 762-0744 Fax. (610) 252-6200

Website: www.smooth-on.com